



**Innovative “vanishing” elevator**

**Modern design that blends  
into your home décor**

**Minimal construction required**

**Quick and easy installation**

# Savaria® Telecab Home Elevator

**MAXIMIZE YOUR LIVING SPACE**



If space is one of your major concerns when finding an innovative and affordable mobility solution for your home, the Savaria Telecab is the answer for you. This two-stop elevator has a modular construction with a guide rail system that eliminates the need for a hoistway so you don't have to worry about complex and costly installations. The Telecab travels through a simple floor cut-out for a vanishing elevator effect leaving you more usable space.

 **savaria.**

# Savaria® Telecab Home Elevator

## MAXIMIZE YOUR LIVING SPACE



- Fully enclosed drive tower designed for safety and aesthetics means that no hoistway or under-unit pit is needed
- Two stops and up to 23' (7 m) of travel, standard cab of 30" x 46" x 78" tall with optional sizes available
- White powder-coated finish with choice of clear or bronze acrylic window panels
- Vacuum-formed ABS plastic trim and mouldings for an enhanced appearance
- Continuous pressure push buttons on board and for hall call stations
- Detector built into the cab roof to stop the unit from moving up when it senses pressure on top of the unit
- Available in different configurations for entry/exit and larger cab sizes
- Safety features include: inside lighting, emergency stop and alarm buttons, battery lowering in case of power failure, telephone, non-skid platform, under-pan sensor to stop the unit if it meets an obstruction, pressure relief valve to prevent platform overload, electro-mechanical door lock, slack chain safety device
- Options include: battery power for up/down, two-door for left and right access, keyed call station, custom cab sizes, custom colors, motorized door operation, hydraulic door closer

## SPECIFICATIONS



Applications	Residential, indoor
Capacity	500 lb (227 kg)
Maximum travel distance	23' (7 m) with 2 stops
Cab dimensions (standard)	30" x 46" (762 mm x 1168 mm)
Cab dimensions (optional)	32" x 53" (813 mm x 1346 mm) 30" x 47" (762 mm x 1194 mm) 32" x 54" (813 mm x 1372 mm) <i>Custom sizes available, ask for details</i>
Speed	20 ft/min (0.10 m/s)
Minimum floor cutout	36" x 60.5" (914 mm x 1537 mm)
Minimum overhead required	96" (2438 mm) to have 6" minimum clearance by code 92" (2337 mm) requires variance
Drive	2:1 roller chain hydraulic
Motor/pump	120 VAC, 3 hp gear type
Warranty	36 months parts, ask for details

Your local authorized dealer can ensure your Savaria product is installed to comply with local and national codes. **Talk to a skilled Savaria dealer about how the Telecab can give you the mobility you need without major construction.**

Authorized Savaria dealer:



[www.savaria.com](http://www.savaria.com)

2 Walker Drive, Brampton, ON Canada L6T 5E1

tel: 800.661.5112 fax: 905.791.2222