



Ideal for public spaces  
including places of  
worship and schools

Quality finished and durably  
built for frequent use

Reliable hydraulic drive  
offers affordable accessibility

Customize to suit your needs  
up to 1400 lb capacity

# Savaria® Prolift® VPL

## RELIABLE COMMERCIAL ACCESS



The Savaria Prolift is a great choice for public spaces such as places of worship, schools and other public spaces where accessibility is needed. The durably constructed ADA-compliant lift operates with simple-to-use constant pressure from a hydraulic drive that delivers a smooth and quiet ride, making it feel like a traditional elevator. Choose the standard Prolift (SCL) or upgrade to the heavy duty (HD) design for heavier loads.

The fully enclosed interior features ceiling lighting, handrail and operating panel with emergency battery back-up for lighting and lowering. Choose from a selection of standard melamine finishes or plastic laminate walls. With features you need, the Savaria Prolift packs great value into a reliable accessibility lift.

# Savaria® Prolift® VPL

## RELIABLE COMMERCIAL ACCESS



- 1:2 cable hydraulic drive delivers reliable performance with a smooth and quiet ride
- Choose the load capacity for your needs from 750 lb to 1400 lb load<sup>1</sup>
- Configure entry/exit (including 90 degree), cab size and number of stops to fit your needs, up to 14' (USA), or 23' (Canada)
- Constant pressure operation with emergency back-up for lighting and lowering included
- Cab is finished in a choice of melamine, fire-rated melamine or plastic laminate<sup>2</sup>
- Hall call stations can be keyless or keyed for added security and finished in stainless steel
- Add fire-rated Pro doors with manual or automatic operation for landings; hinges, automatic door operator and door lock are concealed in the frame for a sleek look
- Automatic floor levelling, emergency stop and alarm included, handsfree telephone optional
- Can be configured for use as a casket lift (white steel cab panel only, as shown top left), or customized with options such as glass and stainless steel cab and doors (as shown bottom left)



## SPECIFICATIONS

Applications	Residential, commercial, indoors
Capacity	<b>SCL:</b> 750 lb (341 kg), 1000 lb (454 kg), optional 1050 lb (476 kg) <b>HD:</b> 1050 lb (476 kg), optional 1400 lb (635 kg) <sup>3</sup>
Maximum travel distance	23' (7 m) Canada, 14' (4.3 m) USA, up to 4 stops
Cab sizes	<b>SCL Types 1, 2, 5:</b> 36" x 48" (914 mm x 1219 mm), 36" x 54" (914 mm x 1372 mm), 36" x 60" (914 mm x 1524 mm), 42" x 48" (1067 mm x 1219 mm) <b>HD all cab types:</b> 42" x 54" (1067 mm x 1372 mm) <sup>3</sup> , 42" x 60" (1067 mm x 1524 mm), 48" x 60" (1219 mm x 1524 mm) <sup>3</sup> Custom sizes available, ask for details
Nominal Speed	30 ft/min (0.15 m/s)
Drive	1:2 cable hydraulic, SCL: 3 HP (2.24 kW), HD: 5 HP (3.73 kW)
Warranty	36 months parts, ask dealer for details

<sup>1</sup> Load capacity varies by local code, check with your authorized Savaria dealer for complete details.

<sup>2</sup> Units required to meet A18.1 2011 & 2014 code require plastic laminate finish or fire-rated melamine.

<sup>3</sup> Where code permits.

**Talk to a Savaria dealer about how the Savaria Prolift can easily and affordably make your building accessible.**

Authorized Savaria dealer:



**savaria.com**

2 Walker Drive Brampton ON L6T 5E1 Canada

tel: 800.661.5112 fax: 905.791.2222