

Courtesy of Silver Cross London



Telecab17



**Innovative  
through-the-floor  
accessibility lift**

**Up to 845 lb capacity  
to accommodate  
mobility equipment**

**No hoistway  
construction required**

# Savaria® Telecab Home Lift

## THROUGH-THE-FLOOR LIFT



The Savaria Telecab was built on the same technology as the company's popular V-1504 wheelchair platform lift and features a robust and reliable hydraulic drive system enclosed in a tower eliminating the need for a separate machine room. The enclosed cab with acrylic panels provides an elevator feel to this accessibility lift.

The Telecab is offered in two design styles and both include a non-skid platform with low threshold and gentle slope for easy wheelchair access. The platform is offered to a size of 36" by 54" for larger equipment access and the constant pressure operation features easy-to-use buttons including emergency stop. Emergency battery lowering and full safety sensor system to detect obstructions is included.

# Savaria® Telecab Home Lift




## THROUGH-THE-FLOOR LIFT



Telecab

- Two-stops and up to 23' (7 m) of travel, residential indoor use only
- White powder coated finish with acrylic panels
- Constant pressure controls with keyed or keyless access
- Full height flush door with optional automatic door operator
- Interior ceiling lighting with handrail or grip handles
- 2:1 roller chain hydraulic drive system
- Nominal speed of 20 ft/minute (0.10 mps)
- Minimum overhead of 96" (2438 mm), or 92" (2337 mm) with variance
- Cab height of 78" (1981 mm) in Telecab, and 80" (2032 mm) in Telecab17
- 24 VDC, 3 Hp (2.1 kW) motor with gear type hydraulic pump
- Power supply required: 110 VAC, 30 A, 60 Hz, single phase (20 A if optional battery back-up is installed)
- Additional safety features include: emergency stop and alarm buttons, emergency battery and manual lowering, telephone, underpan obstruction sensor, cab-top obstruction sensor, pressure relief valve to prevent platform overload, door interlock system, slack chain safety device
- Optional battery power back up for up/down up to 5 trips
- 36 month parts warranty, see dealer for details

### SPECIFICATIONS

	Telecab	Telecab17
<b>Capacity</b>	500 lb (227 kg)	845 lb (384 kg)
<b>Cab sizes</b>		
	30" x 47" (762 mm x 1194 mm) 32" x 54" (813 mm x 1372 mm)	N/A
	30" x 47" (762 mm x 1194 mm) 32" x 54" (813 mm x 1372 mm)	N/A
	30" x 46" (762 mm x 1168 mm) 32" x 53" (813 mm x 1346 mm)	30" x 46" (762 mm x 1168 mm) 36" x 54" (914 mm x 1372 mm)
<b>Minimum floor cutout</b>	36" x 60.5" (914 mm x 1537 mm)	60.5" x 35.25" (1537 mm x 895 mm) for 30" x 46" cab 68.5" x 41.25" (1740 mm x 1048 mm) for 36" x 54" cab

Your local authorized dealer can ensure your Savaria product is installed to comply with local and national codes.

**Talk to a skilled Savaria dealer about how the Telecab can give you the mobility you need without major construction.**

Authorized Savaria dealer:



savaria.com

2 Walker Drive Brampton ON Canada L6T 5E1

tel: 800.661.5112 fax: 905.791.2222