

photo courtesy of Access Lifts and Service, Hopewell Cancer Center

**Rugged construction
ideal for outdoor
or indoor use**

**Reliable operation with
robust components**

**Ideal for deck and
porch access**

**Travels up to 72"
with 2 stops**

Savaria® Multilift

VERTICAL PLATFORM LIFT

RELIABLE AND EASY ACCESS

Gain convenient, easy and reliable access with the Savaria Multilift vertical platform lift. The Multilift easily accommodates a person with wheelchair with its 750 lb capacity. Built with durability in mind, the Multilift is up for the challenge of tough climate conditions. You can count on this lift for reliable performance and ease of operation. An ideal deck lift for home use, the Multilift is also approved for certain public accessibility projects with the optional commercial package. The lift is available in standard beige, or choice of custom color, with landing and platform gates in solid metal or with glass or acrylic inserts.

 **savaria.**

Savaria® Multilift

VERTICAL PLATFORM LIFT

RELIABLE AND EASY ACCESS



- ACME screw drive with back-up nut provides reliable operation and 750 lb capacity
- Self-supporting tower houses mechanical components, installs with securement to concrete pad
- Constant pressure controls with keyed access on car and call stations
- Non-skid zinc-coated platform available in 3 standard sizes with optional 36" and 42" widths. Note that 42" platform requires additional support for tower
- Automatic access ramp for easy on/off (16" residential, 24" commercial) and side guard panels (42 1/8")
- Safety features include underpan sensor to stop lift when it meets an obstruction, manual lowering device, emergency stop button, electro mechanical lock on landing gate
- Options: grab rail, fixed access ramp, emergency light and alarm on car, weather resistant lock for outdoor use, 90-degree access, 36" or 42" wide platform, optional travel to 72", custom color platform and landing gates with acrylic or glass inserts, battery back-up system for emergency use, joystick, pendant control, powered gate, fold-out seat
- Optional Savaria Link system for trouble-shooting and lift technician diagnostics
- The Multilift is also available with a factory-built enclosure or as a mobile unit

SPECIFICATIONS

Applications	Residential (indoor/outdoor), commercial ¹
Capacity	750 lb (340 kg)
Maximum travel distance	48" (1.219 m), optionally 72" (1.829 m)
Platform sizes available (standard)	34" x 48" (863 mm x 1219 mm), 34" x 54" (863 mm x 1371 mm), 34" x 60" (863 mm x 1524 mm) 36" (914 mm) and 42" (1067 mm) wide platforms optional (42" not self supporting)
Speed	8 ft/min (.04 m/s)
Drive	1 hp 110 VAC, or optional 1 hp 24-volt and battery model
Warranty	36 months parts, ask dealer for details

¹ Commercial applications comply with ASME A18.1 (US) and B.355 & B.613 (Canada), state and local codes may differ. Please consult your local Savaria dealer about code requirements in your jurisdiction.

A solid flush landing gate with lock is required for all commercial applications and travel above 24" (Canada) and 30" (USA) in residential applications.

Authorized Savaria dealer:



2 Walker Drive Brampton ON L6T 5E1 Canada
savaria.com tel: 1.855.728.2742