



**On-demand
accessibility without
significant renovations**

**Custom built to fit
stairs with curves
or multiple levels**

**ADA-compliant
platform available**

*< Outdoor application with
stainless steel rails (shown left)*

Savaria® Pegasus

INCLINED PLATFORM LIFT

ACCESS OVER STAIRS WITH CURVES OR MULTIPLE LEVELS



When you need wheelchair access over stairs with multiple levels, curves or intermediate landings, the Savaria Pegasus inclined platform lift (IPL) is a flexible, cost-effective choice with its space-saving foldaway design and optional out-of-the-way parking. Whether for a place of business, worship or any public space, each unit is custom-built to the specific measurements of the project to provide a smooth and comfortable ride. Optional configurations include vertical bend, steep start, 90° turn, 180° turn and special bends.

Safety features include an obstruction sensor system on the platform, non-skid platform with side safety flaps, overspeed governor, manual lowering device, keyed access for call stations and emergency stop button.

Savaria® Pegasus

INCLINED PLATFORM LIFT

ACCESS OVER STAIRS WITH CURVES OR MULTIPLE LEVELS



- Custom designed for access over stairs with multiple levels, curves or landings
- Space-saving design with foldaway platform for full access to stairs when lift is not in use
- Ideal solution when an elevator or vertical platform lift cannot be accommodated
- Minimal construction needed with no machine room required
- Optional custom colors for rails or carriage, or stainless steel rails
- User-friendly continuous-pressure operation with motorized folding platform, automatic ramps and powered folding safety arms, optional side ramp access

SPECIFICATIONS

Stair types	Multiple levels of straight stairs, stairs with intermediate landings, stairs with turns
Applications	Indoor, outdoor, residential, commercial
Power supply	208-240 VAC, 50/60 Hz, single phase on dedicated 20 amp circuit
Drive system	2 hp rope drive, optional compact drive
Platform sizes	31.5" x 41.3" (800 x 1050 mm), 31.9" x 48" (810 x 1220 mm), custom platform sizes available
Capacity	660 lb (300 kg) up to 45° angle
Nominal speed	20-30 ft/min (0.10-0.15 m/s), 10 ft/min (0.05 m/s) through curves
Finishes	White (RAL 9003), custom color available Outdoor units require upgrade stainless steel rail
Optional configurations	Vertical bend, steep start, custom bends, 90° or 180° parking Maximum travel is 164 ft (50 m)
Optional features	Folding passenger seat, stabilizer for travel under 20°, keyed access
Call station	Surface mounted, optional free-standing pedestal
Safety features	Emergency stop, pedestrian alert and light while lift is in use, underpan sensor, safety brake, manual platform folding
Warranty	24-month manufacturer's parts warranty, ask for details

Outdoor applications are limited by your specific climate conditions, consult with your local dealer

For complete specifications, options and compliance to local code requirements, please contact your local authorized Savaria dealer. To locate a dealer near you, visit our web site at [Savaria.com](https://www.savaria.com) or call us **1.855.728.2742**.



Authorized Savaria Dealer:



[savaria.com](https://www.savaria.com)

2 Walker Drive Brampton ON L6T 5E1 Canada

tel: 1.855.728.2742

Savaria makes every effort to publish accurate information. Some specifications, options or features may vary by market or change without notice.

©2025 Savaria Corporation.